

How to Flash the ATS

2/9/2011

- Make sure the ATS & Ground Speed are OFF
- Put SD Card in ATS
- Turn on Truck
- Light for SD Card on ATS box should come on & flash
- Wait a few minutes
- Turn truck off
- Remove SD Card
- Turn truck back on
- Check the MDC Screen & make sure NaCl appears under Solid Material
- Turn on Ground Speed
- Turn on liquid
- You should see rate on ground speed
- Put Ground Speed on Manual
- Hit Blast
- Now check the MDC Screen to see if your Liquid & the rate is showing up on the MDC

NOTE: Sometimes you need to Flash the ATS again, if it does not work the first time.

*The SD card will no longer have the configuration files on it, so you will have to put them back on before using it to flash another ATS.