

## Installation Instructions of ATS Removal of GL400 Screen & Connection of Box

### Material List:

- 1 Box
- Power cord
- 2 Cables
  - Female end to Female end
  - Female end to Round end
  
- Screw drivers
- Allan Wrenches
- Chip extractor
- Flashlight
- Grounding wrist band
- Keyboard (USB plug in)

1. Lay out materials (Figure 1)
2. Unscrew the GL400 screen (2 screws) so that you can get into the wires behind (Figure 2).
3. Unplug the two round cables connected to the back of the screen enclosure (Figure 2).
4. Unplug the cable connected to the bottom of the screen enclosure, so you can remove the screen entirely (Figure 3).
5. Set screen aside for chip exchange. **See Chip Exchange Instructions (for GL400 only).**
6. On the side of the enclosure where the screen was just taken off, there is a hole. Take the cable with the round end and shove the round end through that hole. It is a tight fit but should go through with encouragement. Plug it in.



Figure 1 - Materials



Figure 2- Unscrew screen




Figure 3 - Unplug screen




Figure 4 - Insert Cable Here



13. The next steps will be on the MDC. **See MDC Computer Instructions.**